



## QUICK START GUIDE

SEE INSTRUCTION MANUAL FOR FULL INSTRUCTIONS AND IMPORTANT SAFETY INFORMATION.

### PRODUCT COMPONENTS

- A. Power/Record Button
- B. Indicator Light
- C. Camera Lens

- D. Night Mode Bulbs
- E. Memory Card Port
- F. Charging Port



### POWER ON/OFF

#### To Power On:

To turn on press and hold **POWER/RECORD** button for 4 seconds.

#### To Power Off:

To turn off press and hold **POWER/RECORD** button for 4 seconds.

### GETTING STARTED

**STEP 1:** To turn on press and hold **POWER/RECORD** button for 4 seconds. (Figure A) LED light will illuminate solid red. Cop Cam™ will start recording video when motion is detected. Ensure Cop Cam™ is oriented as shown so video is upright. (Figure B)

**STEP 2:** To switch to photo mode press and hold the **POWER/RECORD** button for 2 seconds. LED light will illuminate solid green. To take a photo quickly press the **POWER/RECORD** button once.

**STEP 3:** To retrieve footage, remove memory card by pressing inward to release, then pull out of slot. (Figure C) Use included USB cable to connect Cop Cam™ to your Computer/Laptop. Access footage following prompts. (Figure D)

**STEP 4:** To charge Cop Cam™, plug into computer/laptop. LED light will alternately flash red and green. (Figure D)

